

## How to Order

## Part Numbering System

Single Input	Rotary Linear	Stroke	Gauges	Limit Switch	Indicator	Special
<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>

<b>Base Part #</b>	
<b>55-3000</b>	Pneumatic
<b>56-4000</b>	Electro-Pneumatic Nema 4
<b>56-7000</b>	Electro-Pneumatic Nema 7

<b>1 Signal Input</b>	
<b>4</b>	3-15
<b>5</b>	4-20
<b>6</b>	Digital
<b>7</b>	Smart

<b>2 Rotary Linear</b>	
<b>R</b>	Rotary
<b>L</b>	Linier

<b>3 Stroke</b>	
<b>2</b>	L-10-80 mm
<b>3</b>	80-150-mm
<b>4</b>	Namur

<b>4 Gauges</b>	
<b>1</b>	Steel
<b>2</b>	Stainless Steel
<b>3</b>	None

<b>5 Limit Switches</b>	
<b>5</b>	SPDT Mechanical
<b>6</b>	1 Proximity
<b>7</b>	2 Proximity
<b>8</b>	4-20 Potentiometer
<b>0</b>	None

<b>6 Indicator</b>	
<b>3</b>	Dome
<b>2</b>	Flat

<b>7 Specials</b>	
<b>S</b>	Special
<b>1</b>	Standard